



alle omskifttere er tegnet i venstre yderstilling

- : 1/2 w modst.
- : 1 w " "
- : 3 w " "
- : 20n = 20000pf prøvesp. 2000V =
- : 50n ~ 50000pf " " 2000V ~
- : 5ns : 5000pf " " 5000V =

A/s S. P. RADIO AALBORG	