

INSTRUCTION MANUAL




Sailor

TYPE R108
R109

A/s S. P. RADIO
AALBORG - DENMARK



INSTRUCTION MANUAL



Sailor

TYPE R108
R109

A/S S. P. RADIO

9000 AALBORG - DENMARK



CONTENTS

| | |
|--|----|
| A. DESCRIPTION OF SAILOR TYPE R108/R109 | |
| I General | 4 |
| II Functions | 4 |
| III Technical Data | 6 |
| IV Dimensional Sketch | 8 |
| B. INSTALLATION OF SAILOR TYPE R108/R109 | |
| I Wire aerial and FM aerial | 9 |
| II Installation of Direction-Finding Equipment | 9 |
| III Speaker and Headphones | 9 |
| IV External Power Supply | 9 |
| V Internal Power Supply | 10 |
| C. OPERATING THE SAILOR TYPE R108/R109 | |
| I General Broadcast Reception | 10 |
| II Telephony and Telegraphy Reception | 11 |
| III Taking Bearings of Consol Radio Beacons | 11 |
| D. TAKING BEARINGS OF CONSOL RADIO BEACONS | |
| I Description of the Consol Direction-Finding System .. | 12 |
| II Details for Stavanger and Bush Mills Consol Radio Beacons | 13 |
| III Consol Chart | 13 |
| E. TAKING BEARINGS OF GENERAL RADIO BEACONS | |
| I Principle | 14 |
| II Sources of Errors | 15 |
| III Wave Types (types of transmission) | 17 |
| IV Selecting a Direction Finder | 17 |
| V Direction Finding Using Conventional Permanently Installed Radio Direction Finder | 18 |
| VI Direction Finding Using the SAILOR Type BK171 Ferrite Navigator | 20 |
| F. SERVICE INSTRUCTIONS | |
| I Adjustment Procedure for SAILOR Type R108/R109 | 22 |
| II Component layout, bottom view | |
| III Component layout, top view | |
| IV Parts Lists | |
| V Circuit diagram | |


A. Description of SAILOR Type R108/R109

I. General

The SAILOR Type R108/R109 is a splashproof transistorised marine receiver for operation on built-in dry cells or from the vessel's lighting system.

The receiver is designed for general broadcast, telephony and telegraphy reception, and for taking bearings of Consol radio beacons, circular radio beacons and broadcasting stations. When operated with a direction-finding aerial the receiver is capable of direction finding on four bands. The R109 can also receive FM broadcasting. A front panel meter facilitates rapid tuning and serves as minimum-signal indicator for direction finding. The meter is also used for checking the voltage of the built-in battery.

A beat-frequency oscillator (BFO) is provided for reception of telegraphy signals and for taking bearings of Consol radio beacons. A bandwidth-reducing filter in the receiver's AF section can be switched in to improve reception of radio beacons.



II. Function

1. AF GAIN – VOLUME CONTROL

Controls volume and is equipped with on/off switch.

2. RF GAIN – SENSITIVITY CONTROL

Controls the receiver's sensitivity level.

3. TONE – TONE SWITCH

With this switch in the HIGH (clear) position, the full tone range is reproduced. The MED position provides moderate treble cut; the LOW position, strong treble cut.

In the FILTER position, the tone range around 1000 Hz is accentuated.

4. FUNCTION – FUNCTION SWITCH (for AM reception)

With this switch you decide if the incoming signal is to be picked up via the normal aerial (switch in HI-IMP position) or via the direction-finding equipment (Ferrite Navigator/Direction-Finding Loop) with the switch in the DF position.

The receiver has a beat-frequency oscillator (BFO) for reception of unmodulated telegraphy and taking bearings of Consol radio beacons and unmodulated circular radio beacons. The BFO can be switched on (BFO ON) and off (BFO OFF) in the HI-IMP as well as in the DF position.

The R108/R109 has automatic volume control (AGC). This is operative with the function switch in the HI-IMP position. In addition, the sensitivity control covers a range wide enough to enable removal of the atmospheric background noise appearing when the incoming signal disappears.

In the DF position, the automatic volume control is inoperative. This implies that the receiver's sensitivity level must be adjusted for a convenient meter reading, using the RF GAIN control. However, the automatic volume control begins functioning when the incoming signal exceeds a level representing twice full-scale meter reading. This function has been introduced to ensure that incorrect handling will have the least possible effect on results obtained.

5. BANDS – ROW OF PUSH-BUTTONS

for selecting between

| | | |
|-----------------|----|---------------|
| Long wave | LW | 150– 260 kHz |
| Navigation wave | NW | 250– 430 kHz |
| Medium wave | MW | 495–1610 kHz |
| Short wave | SW | 1600–4500 kHz |

6. TUNING

7. DIAL

Calibrated in kHz.

The rim of the dial has a white ring on which the most frequently received stations may be marked in pencil.

8. R108:

DIAL LIGHT – SWITCH

for selecting between two brilliance levels. NORMAL for use in partial darkness and DIMMED for use at night.

In order to avoid unwanted battery drain, the light turns off automatically when the knob is released.

R109:

AM/FM SWITCH.

Selects between AM and FM bands.

9. **METER**
10. **BUILT-IN SPEAKER**
8 ohms, with large diaphragm and magnet.
11. **Ext. 8-ohm SPEAKER or HEADPHONES**
Connection for external 8-ohm speaker or headphones.
Plug: Unipolar jack plug.
12. **POWER**
Connection for earth and external power supply, 12–32 V without voltage switching.
Socket: Hirschmann Mek 60 bz.
13. **DF**
Connection for BK171 or FB175 direction-finding equipment.
Plug: Hirschmann Mes 60 bz.
14. **HI-IMP AERIAL**
Connection for wire aerial.
Plug: Belling & Lee.
15. **FM-AERIAL**
Socket: Belling & Lee.
Connection for FM aerial.
16. **POWER SWITCH**
Selects between internal or external power supply, and Battery Test.
17. **BATTERY BOX COVER**
Instructions for battery replacement are given on the battery cover.
18. **Dial light (R109 only).**

III. Technical Data

1. Bands:

| | | |
|-----------------|----|---------------|
| Long wave | LW | 150– 260 kHz |
| Navigation wave | NW | 250– 430 kHz |
| Medium wave | MW | 495–1610 kHz |
| Short wave | SW | 1600–4500 kHz |
| | FM | 88– 108 MHz |

2. Sensitivity:

10 dB (S+N)/N (modulation 30 % – 400 Hz).

Tone switch at HIGH

LW better than 5 μ V




NW better than 4 μ V

MW better than 4 μ V

SW better than 3 μ V

FM better than 1 μ V 20 dB S+N/N Δ f = \pm 22.5 KHz

3. Image Rejection:
LW > 90 dB NW > 80 dB MW > 70 dB SW > 60 dB
FM > 45 dB
4. Intermediate Frequency:
AM: 462 KHz FM: 10.7 MHz
5. Selectivity:
AM: Typically ± 4 KHz -6 dB
 ± 8 KHz -60 dB
FM: ± 120 KHz -3 dB
6. AGC Characteristic:
Increasing the input voltage from 100 μ V to 300 mV causes a 1 dB change in output voltage.
7. AF Characteristic: (AM) only
HIGH : 4 kHz -6 dB
MED : 1.2 kHz -6 dB
LOW : 600 Hz -6 dB
FILTER: 1 kHz ± 300 Hz
8. AF Output:
1.6 watts at less than 5 % distortion.
9. Power Supply:
Built-in power supply:
Six 1.5-volt dry cells (Helleisen Type 736 IEC R20). Always use All Steel (leak-proof) cells.
External power supply:
12-32 volts without voltage switching.
10. Cabinet and Finish:
All-welded Rilsan rust-proofed steel cabinet. All controls and the ornamental ring are of bright chromium-plated brass.



B. Installation of SAILOR Type R108/R109

I. Wire Aerial and FM Aerial

The external aerial plugs into the socket marked HI-IMP AERIAL. The aerial should consist of a wire 5–15 metres long and placed as high and in the clear as possible. Good-quality coaxial cable should be used for the down-lead. It is of decisive importance to keep the down-lead as short as possible and install it so that it is clear of other electric cables. All joints should be soldered. For best FM reception, an FM aerial should be plugged into the socket marked FM AERIAL. Use a horizontally polarised omnidirectional aerial. If a separate FM aerial is not connected to the set, FM will be automatically received from the wire aerial.

Use of a separate FM aerial is recommended in the interests of best reception.

II. Installation of Direction-Finding Equipment

SAILOR BK171 Ferrite Navigator

The BK171 plugs into the multisolet marked DF on the side cover of the receiver cabinet.

Permanently Installed Direction-Finding Loop

Plug the SAILOR FB175 Transformer Box into the multisolet marked DF on the side cover. Place the Transformer Box as close to the R108 as possible.

The SAILOR 26F or 26FA Direction-Finding Loop should be placed as much in the clear as possible. The double-screened cable between the Transformer Box and the Direction-Finding Loop may have any length between 0.5 and 4 metres.

The sense aerial should be a vertical aerial, 3–15 metres long. For connection of the sense aerial see the installation instructions supplied with the FB175.

III. Speaker and Headphones:

A speaker and/or headphones plug(s) into the socket marked Ext. 8-ohm SPEAKER or HEADPHONES.

IV. External Power Supply

An external power supply and earth should be connected at the EXT. POWER multiplug. Be sure to observe correct polarity.

The receiver may be operated on all DC voltages between 12 and 32 volts without switching.

The fuse, one 1-amp. unit, is placed to the left in the bottom of the receiver and becomes accessible after the receiver has been removed from its cabinet.

Before applying power to the receiver, any ignition systems, dynamos and electric motors on board must be effectively treated to suppress noise. This is of decisive importance if the full benefit of the receiver is to be realised.

The earth connection should consist of not less than 2.5 mm² insulated copper cable and go to the hull (in iron vessels) or keel bolt, engine base, or not less than 1 m² metal sheet on the outside of the hull below the water line (in wooden vessels). The earth wire should be as short as possible. A good earth connection is of considerable importance for noise-free reception and sharp direction-finding minima.

V. Internal Power Supply

The internal battery is located behind the cover marked BATTERY BOX. Six 1.5-volt dry cells should be used for replacement (Hellsen Type 736 or equivalent). Be sure to observe correct cell polarity (see drawing on cover).

The voltage of the built-in battery can be checked with the power supply switch (POWER) in the BATT. TEST position. The battery should be replaced when the voltage goes below 7 volts (meter reading = 3.5).

Warning: Do not leave a spent battery in the battery box.

Spent batteries leak acid which may damage the set beyond repair.

C. Operating the SAILOR Type R108/R109

I. General Broadcast Reception:

AM Broadcasting:

1. Set POWER SWITCH to the desired type of power supply.
2. Apply power to the receiver by turning its volume control (AF GAIN) clockwise.
3. Set FUNCTION switch to HI-IMP aerial without BFO (BFO OFF). Set AM/FM switch to AM.
4. Depress the push-button for the wave band of your choice (in the row marked BANDS). Most broadcasting stations are in the medium wave (MW) and long wave (LW) bands.
5. For broadcast reception, set the sensitivity control (RF GAIN) to maximum.

6. Set the volume control (AF GAIN) to desired volume.
7. Set TUNING to the station of your choice. Tune for maximum meter reading. If you want the dial lighted, turn the DIAL LIGHT knob.
8. Set TONE switch for the desired type of AF response. The HIGH, MED and LOW positions may be used for broadcast reception.

FM BROADCASTING (R109 only):

1. Set POWER SWITCH to the desired type of power supply.
2. Apply power to the receiver by turning its volume control (AF GAIN) clockwise.
3. Set AM/FM switch to FM.
4. Set TUNING to the station of your choice. Tune for maximum meter reading. If you want the dial lighted, depress the DIAL LIGHT knob.

II. Telephony and Telegraphy Reception

1. Set POWER SWITCH for the type of power supply you wish to use.
2. Apply power to the receiver by turning its volume control (AF GAIN) clockwise.
3. Set FUNCTION switch to HI-IMP BFO OFF, for telephony reception; or to HI-IMP BFO ON, for telegraphy reception.
4. Depress the push-button for the wave of your choice (in row marked BANDS). Most communication stations are in the short-wave (SW) band.
5. For telephony reception, use both the sensitivity (RF GAIN) and the volume (AF GAIN) controls for adjustment of volume, selecting that combination of settings of the two controls which provides minimum noise interference in the given situation. For telegraphy reception, the volume control will usually be set to maximum, using only the sensitivity control for adjustment of volume.
6. Set the TUNING control to the station of your choice. If you want the dial lighted, turn the DIAL LIGHT knob.
7. For telephony reception, set the TONE switch to either HIGH, MEDIUM or LOW.
For telegraphy reception use either the LOW or the FILTER position.
8. Telegraphy reception requires precise setting of the TUNING control. Tune carefully for maximum volume.

III. Taking Bearings of Consol Radio Beacons

Set the receiver's controls as for telegraphy reception under II (for complete instructions see Chapter D).

D. Taking Bearings of Consol Radio Beacons (not possible on FM Broadcast band)

I. Description of the Consol Direction-Finding System

The following should be taken only as an introduction to the Consol direction-finding system. For additional information about the subject reference should be made to the publications issued by the proper government authorities.

Using the Consol direction-finding system it is possible to determine one's exact position, provided the approximate position is known, by taking cross bearings of two Consol radio beacons with the SAILOR R108 or R109.

A Consol beacon consists of a circular radio beacon which transmits the beacon's call sign and a continuous signal, and a directional beacon which transmits different signals in different directions. Transmissions take place alternately as specified in »Details for Stavanger and Bush Mills Consol Radio Beacons«. The circular transmission serves for tuning the receiver to the wanted beacon, as to a general telegraphy station, see Section II of Chapter C. Below is shown a chart with two stations, Stavanger and Bush Mills, of special interest in the North Sea and North Atlantic. For each of the two stations are indicated the moments at which transmissions of the directional beacons start. These transmissions consist of sectors.

Every second sector (the A sectors) comprises 60 dots; the other sectors (the B sectors) consists of 60 dashes. These signals are transmitted for a period whose length is indicated on the chart. The dividing lines between sectors are indicated as »beams«. Along each beam, dots and dashes unite into a continuous signal. The sectors rotate in the directions of the arrows at the uniform speed of exactly one sector-width during the time a transmission from a directional beacon is in progress. Hence, from the position marked X in the North Sea you will hear from the Stavanger Consol radio beacon first 48 dots until the »S« beam passes by, then 12 dashes, ending the transmission. This is followed by a circular transmission, etc. etc. From Bush Mills, you will first hear 28 dashes until the passage of the »BM« beam, after which 32 dots will be heard. It will then be easy, using the quite simple diagrams issued by the proper government authorities, to determine the exact bearings of the Consol beacons as the diagrams give the bearing in degrees corresponding to the number of dots and dashes heard since the moment the directional transmission started.

Near the beams, since these are not sharply defined, a number of dots and dashes will not be heard, or heard only indistinctly. Accordingly, you count all dots and dashes during a transmission period.

If you count, say a total of 54 dots and dashes it means that $60 - 54 = 6$ characters have been lost. This number you divide into 3 dots and 3 dashes and add these to the number counted. You now have the figure to be used for plotting on the diagram.

Maximum bearing accuracy is obtained near the beam centre, where it averages $\pm 0.2^\circ$, decreasing as the ambiguous sectors are approached. In sectors bordering on the ambiguous sectors, errors of $\pm 0.5^\circ$ by day and $\pm 1.5^\circ$ by night must be expected. Bearings should not be taken in the ambiguous sectors and less than 25 nautical miles from Consol radio beacons.

II. Details for Stavanger and Bush Mills Consol Radio Beacons

STAVANGER:

Position: $58^\circ, 37', 32''$ N. $5^\circ, 37', 49''$ E.

Frequency: 319 kHz (940 m).

Call sign.: LEC . — . . . — . — .

Signal: A. Gen. circular transmission

- | | |
|--------------------------|---------|
| 1. Letters LEC | 6 sec. |
| 2. 1 long dash | 50 sec. |
| 3. Pause | 3 sec. |

B. Directional transmission

- | | |
|--------------------------------------|---------|
| 1 dot or dash every second | 60 sec. |
| Pause | 1 sec. |

Total duration of each transmission period is therefore 120 sec.

Transmitting schedule: Round the clock. — Range: approx. 850–1300 nautical miles.

BUSH MILLS:

Position: $55^\circ, 12', 20''$ N. $6^\circ, 28', 0.2''$ W.

Frequency: 266 kHz (1128 m).

Call sign.: MWN — — . — — — .

Signal: A. General circular transmission


Continuous transmission interrupted
by call sign 30 sec.

B. Directional transmission

1 dot or dash every 0.5 sec. 30 sec.

Total transmission period 60 sec.

Transmitting schedule: Round the clock except between 15:00 and 15:15 GMT.



E. Taking Bearings of General Circular Radio Beacons

I. Principle

Determining one's position by direction finding is done by taking compass bearings of not less than two, preferably three or four radio beacons of known geographical locations. These compass bearings are plotted on a chart, and their intersection point indicates the position of the vessel.

Compass bearings are taken by means of a direction finder connected to the receiver. A direction finder can take various forms but always comprises a directional aerial and one or more dials calibrated in degrees. When the direction finder is rotated, the signal strength will be dependent on the angle between the direction-finding aerial and the direction to the beacon. If rotated 360° , the direction finder will pass through two maxima and two minima. The two minima, which are spaced 180° apart, are better defined than the maxima and are therefore employed for direction finding. Consequently, using the direction finder you can determine the exact direction to the beacon, reading the direction on the graduated dial either as an angle relative to the vessel's centerline (in which case the angle is called the relative bearing) or as an angle relative to north (the compass bearing).

If the direction finder gives the relative bearing, the compass bearing can be found by adding the relative bearing to the compass course. On SAILOR direction-finding loops, this addition can be done by setting another graduated dial according to the compass course.

As stated above, two minima will be found on rotating the direction finder 360° , and only one of these minima is the correct one, the other being 180° opposite. However, using the sensing device of the direction finder you can determine which minimum is the correct one. This operation is known as sense determination and is described in detail in the sections covering the individual direction finders.

Direction finding can be done on all bands (BANDS). However, a certain amount of inaccuracy should be expected when taking bearings of stations other than actual radio beacons. The reason is that radio beacons are built and set up with special attention being given to their application.

The fundamental principle when setting the receiver for taking bearings of one or more stations transmitting on the same frequency is first to tune the receiver to the station on the general aerial, thereafter switching to the direction-finding aerial and doing the actual direction-finding job.

The old saying that practice makes perfect applies here too. You cannot expect good results without previous training.

It is therefore very important to practice the procedure described in item V or VI (depending on the type of direction finder employed) under good weather conditions at a known position.

II. Sources of Errors

The following factors are possible causes of errors in radiolocation work:

1. Magnetic variation.
2. Local compass error.
3. Local radio direction finder error.
4. Coastal refraction.
5. Night effect.

To determine the compass bearing of a beacon by means of the radio direction finder, the compass course is used as starting point as described in the preceding section, bearing in mind that:

True course = compass course (read course) + variation + local compass error.

The variation is taken from a chart, and the local compass error from the local compass error table, in the usual manner.

The local radio direction finder error is due to the action of the vessel's metal parts such as rigging, mast, hull etc. It is dependent on the location of the direction-finding aerial on the vessel and on the angle of the bearing relative to the vessel's center line. Hence bearings should always be taken from the same place on the vessel.

Also, a correction table should be drawn up for the direction finder operated in that particular place.

To make such a table, the vessel is swung near a radio beacon within optical sight, finding at every 10° or so the difference between optical relative and radio relative bearing.

Coastal refraction may occur where beacon signals must travel partly over land and partly over the sea to reach the vessel or if they leave the shore at a very acute angle. The use of radio beacons should therefore be avoided where these possibilities of errors exist.

Night effect is a bearing error due to intermixing of radio signals reaching the receiver along the surface of the earth and radio signals arriving after having been reflected from the ionosphere. This effect is especially in evidence at night, in particular from one hour before to one hour after sunset and sunrise, and manifests itself as flattening and/or »creeping« of minima. The night effect also varies with the seasons, and is dependent on the geographical position, being smallest at the equator. Under such conditions it is advisable to employ beacons that are as near the vessel as possible and to employ bearings with some caution. If more than one frequency is available, the lowest should as a rule be preferred. This will provide maximum bearing accuracy with a minimum of disturbance from fading and night effect.

Example of Correction Table for Radio Direction Finder:

| Read Relative Bearing | Correction | Read Relative Bearing | Correction |
|-----------------------|------------|-----------------------|------------|
| 0° | 0 | 190° | +1 |
| 10° | +2 | 200° | +3 |
| 20° | +4 | 210° | +5 |
| 30° | +6 | 220° | +7 |
| 40° | +7 | 230° | +8 |
| 50° | +7 | 240° | +9 |
| 60° | +7 | 250° | +8 |
| 70° | +6 | 260° | +7 |
| 80° | +4 | 270° | +5 |
| 90° | +2 | 280° | +2 |
| 100° | 0 | 290° | 0 |
| 110° | -2 | 300° | -3 |
| 120° | -4 | 310° | -4 |
| 130° | -5 | 320° | -4 |
| 140° | -5 | 330° | -4 |
| 150° | -4 | 340° | -3 |
| 160° | -3 | 350° | -2 |
| 170° | -1 | 360° | 0 |
| 180° | +1 | | |

Correction = Optical relative bearing minus
read radio relative bearing

III. Wave Types (types of transmission)

The R108/R109 is designed for the reception of four different wave types:

A₀: Constant unmodulated carrier. This wave type can be received only on receivers which, like the R108/R109, are equipped with a beat-frequency oscillator (BFO). (The BFO converts the unmodulated signal so that it can be perceived acoustically). The A₀ signal is excellently suited for taking bearings but has the considerable drawback that station identification is difficult (all stations sound the same).

A₀ occurs rarely in radio direction finding.

A₁: Unmodulated telegraphy. Morse characters are produced by turning an unmodulated carrier on and off. Reception of such a carrier requires a BFO.

A₁ is rarely used in radio direction finding.

A₂: Modulated telegraphy. Morse characters are produced by interrupted tone modulation on a constant carrier (less often both modulation and carrier are interrupted simultaneously).

A₂ is generally received without a BFO, but use of the BFO can be an advantage under certain conditions.

A₂ is without comparison the most widely used wave type for radio beacons.

A₃: General broadcasting and AM telephony. The carrier is modulated with music or speech.

A BFO is not normally used for reception of this wave type. However, using a BFO will often be advantageous if it is desired to take the bearing of an A₃ signal.

A₃ is never used by actual radio beacons.

IV. Selecting a Direction Finder

Two types of direction finder are available for the SAILOR R108/R109:

1. SAILOR BK171 Ferrite Navigator

This direction finder is specially suited for use in small boats of plastic or wood.

Advantages of this equipment are simple operation, modest space requirements, simple installation, insensitivity to heeling (sailing boats), and a fixed-mounted sense aerial.

The BK171 is not suited for use in metal vessels.

2. Permanently Installed Loop

SAILOR 26F/FB175 or

SAILOR 26FA/FB175.

This type of equipment should be chosen for larger, spacious vessels and for fishing craft and coasters.

These direction finders are more difficult to install and operate than the Ferrite Navigator, but if used by a skilled operator and the vessel can be kept on a stable course while bearings are being taken it will provide somewhat better accuracy than is possible with the BK171 Ferrite Navigator.

V. Direction-Finding Using Conventional Permanently Installed Radio Direction Finder

1. Apply power to the receiver by turning the volume control (AF GAIN) clockwise. Set AM/FM switch to AM. (Only R109).
2. Set the function switch (FUNCTION) to HI-IMP BFO OFF (if wave type used by beacon is A_0 or A_1 , use HI-IMP BFO ON).
3. Depress proper button in row marked BANDS.
4. Set sensitivity control (RF GAIN) to maximum.
5. Set dial to beacon frequency. When beacon is heard, retune for max. volume. Readjust volume control (AF GAIN) if necessary.
6. Set TONE switch to the position (HIGH, MED, LOW or FILTER) providing best possible signal.
7. Switch from conventional aerial to direction-finding aerial by turning the FUNCTION knob two steps clockwise (e.g. from HI-IMP BFO OFF to DF BFO OFF).
8. Select on the Direction Finder (FB175) the wave band corresponding to the receiver setting and rotate the TUNE knob of the Direction Finder for maximum volume.
9. Rotate the sensitivity control (RF GAIN) until convenient meter reading is obtained (approx. half-scale deflection).
Readjust volume if necessary, using the volume control (AF GAIN).
10. Set the loose graduated disc so that 360° is against the red pointer.
11. Rotate the Direction Finder until a minimum is obtained.
A minimum is indicated either by minimum signal in the headphones or speaker, or by minimum receiver meter reading. Lock the Direction Finding Loop, using the grub screw, and note down *true* compass course at the moment the bearing is taken.

12. Read the relative bearing against the blue pointer, and read in the Direction Finder's correction table the amount of correction corresponding to that relative bearing.
13. Add the correction found under item 12 to the *true* compass course noted down under item 11 and rotate the plexiglass dial until the red pointer is against the degree number found by the addition.
14. Read, against the blue pointer, the *true* radio compass bearing.
15. If required, the sense-direction can be found by rotating the direction-finding loop approx. 90° anti-clockwise (90° opposite sun). If the volume (meter reading) increases when the SENSE button is pressed, the radio compass bearing found under item 14 is the course *towards* the radio beacon whereas decreasing signal strength indicates that the course is *away* from the beacon.

Example

A bearing of the Hals Barre Beacon, Denmark, is required. The following data apply to this beacon:

Transmitting frequency: 310.3 kHz.

Wave type: A_2 .

Transmitting schedule: hour + 1 min., hour + 4 min., hour + 7 min.

Identification signal: Morse code for HB: —....

- a. Tune the receiver and direction finder to 310.3 kHz as described under items 1 to 10 inclusive.
- b. Wait until the Morse code for HB are heard (several beacons transmit on the same frequency).
- c. Perform item 11.
True compass course is noted down as being 270° (found as read compass course + variation + local compass error).
- d. Perform item 12.
Relative bearing is read against the blue pointer as being 90° . The correction for the direction finder is found by connecting 90° in the table with + 2° (example on page 16).
- e. Set, by rotating the plexiglass dial, the red pointer against $270^\circ + 2^\circ = 272^\circ$ (item 13).

- f. Read, against the blue pointer, the true radio compass bearing as being 2° .
- g. Perform sensing as described under item 15.
The signal strength decreases when the SENSE button is pressed. The true radio compass bearing read under item f is therefor the course away from the beacon.
(The course *towards* the beacon is $180^{\circ} + 2^{\circ} = 182^{\circ}$).

VI. Direction-Finding Using the SAILOR Type BK171 Ferrite Navigator

1. Apply power to the receiver by turning the volume control (AF GAIN) clockwise. Set AM/FM switch to AM. (Only R109).
2. Set the function switch (FUNCTION) to HI-IMP BFO OFF. (If wave type used by beacon is A_0 or A_1 , use HI-IMP BFO ON).
3. Depress proper button in row marked BANDS.
4. Set sensitivity control (RF GAIN) to max.
5. Set dial to beacon frequency. When beacon is heard, retune for max. volume.
Readjust volume control (AF GAIN) if necessary.
6. Set TONE switch to the position (HIGH, MED, LOW or FILTER) providing best possible signal.
7. Switch from conventional aerial to direction-finding aerial by turning the FUNCTION knob two steps clockwise (e.g. from HI-IMP BFO OFF to DF BFO OFF).
8. Select on the Ferrite Navigator the wave band corresponding to the receiver setting and rotate the TUNE knob on the Ferrite Navigator for maximum volume.
9. Rotate the sensitivity control (RF GAIN) until convenient meter reading is obtained (approx. half-scale), and repeat item 8.
Readjust volume if necessary, using the volume control (AF GAIN).
10. Rotate the Ferrite Navigator until a minimum is obtained. A minimum is indicated either by minimum signal in the headphones or speaker, or by minimum receiver-meter reading.
A sharper minimum can be obtained by readjusting RF GAIN.
11. The magnetiv radio compass bearing of the beacon can now be read directly in the prism of the bearing compass. (True radio compass bearing is obtained by adding the variation to the read compass bearing).

12. If necessary, the sense-direction can be found by rotating the Ferrite Navigator approx. 90° anti-clockwise and pressing the SENSE button (be sure to install the sense aerial).

If the volume (meter reading) decreases when the SENSE button is pressed, the radio compass bearing found under item 11 is the course *towards* the beacon whereas increasing signal strength is an indication that the course is *away* from the beacon.

NOTE: It is important that the meter reads approx. half-scale before pressing SENSE button (adjust with RF GAIN).

When using a Ferrite Navigator, local compass error and local radio direction finder error are not usually taken into account.

These correction factors are as a rule small in plastic and wooden boats if regard is paid to the factors covered by Section II of Chapter E.

The correction for variation referred to under item 11 may also be omitted if consistent use is made of the magnetic compass rose on the chart in fixing one position.

Example

A bearing of the Hals Barre Beacon, Denmark, is required. The following data apply to this beacon:

Transmitting frequency: 310,3 kHz.

Wave type: A_2 .

Transmitting schedule: hour + 1 min., hour + 4 min., hour + 7 min.

Identification signal: Morse code for HB: — . . .

- Tune the receiver and Ferrite Navigator as described in items 1 to 9 inclusive.
- Wait until the Morse code for HB are heard (several near-by beacons transmit on the same frequency).
- Perform item 11.

Magnetic radio compass bearing is read as being 180° .

- Perform sensing as described under item 12.

The signal strength decreases when the SENSE button is pressed.

Result

Magnetic course towards the beacon = 180° .

To obtain true course, add the variation (of the chart) to the found value of 180° .

F. Service Instructions

I. Adjustment Procedure for SAILOR Type R108/R109

All alignment points are factory sealed, and readjustment should be undertaken only if necessary because of repair.

Requisite Instruments:

Signal generator (e.g. Philips HF Generator PM 5324).

Multimeter

Oscilloscope (switched to AC or DC).

Switch Settings:

Items 1 to 7 incl. should be performed with the AM/FM switch in the AM position.

Items 8 to 11 incl. should be performed with the AM/FM switch in the FM position (R109 only).

1. Adjustment of No-signal Current in AF Output Amplifier

- 1.1 Unsolder resistor R147.
- 1.2 Switch multimeter to operate as milliammeter and connect between chassis potential and collector of T106.
- 1.3 Turn AF GAIN potentiometer to minimum.
- 1.4 With potentiometer P103, adjust no-signal current to 2–3 mA.

2. Zero Adjustment of Front-panel Meter

- 2.1 Set function switch to HI-IMP. BFO OFF. Turn RF GAIN potentiometer to minimum. No signal at aerial input.
- 2.2 With potentiometer P104, adjust meter reading to 0.

3. Adjustment of AM Intermediate Frequency:

- 3.1 Set receiver to short-wave (BANDS – SW). Set function switch to HI-IMP. BFO OFF position. Turn RF-GAIN potentiometer to maximum.
- 3.2 Connect signal generator through capacitor (approx. 0.1 μ F) to base of mixer transistor T101. Set frequency to 462 kHz.
- 3.3 Adjust coil L115 for maximum meter reading. Signal generator output should be low enough so that meter does not read above 3.
- 3.4 In the event of faults in the intermediate-frequency filter, with ceramic resonators, the complete unit should be replaced (state filter colour coding if necessary) without realigning coils L201 and L202. At the factory, these coils are adjusted with a sweep generator (5 Hz sweep) for symmetrical curve from at 462 Hz with minimum ripple at top.

4. Adjustment of Intermediate-frequency Series Trap

- 4.1 Set receiver to navigation band (BANDS – NW) with variable capacitor C129 at minimum capacitance, function switch at DF BFO OFF, and RF GAIN potentiometer at maximum.
- 4.2 Connect signal generator to capacitor C131 (diodes D101 and D102. Set frequency to 462 kHz.
- 4.3 Adjust coil L113 for minimum meter reading.

5. Adjustment of Beat Oscillator

- 5.1 Function switch at DF BFO ON, RF GAIN potentiometer turned to maximum.
- 5.2 Connect signal generator as in item 3.2.
- 5.3 Adjust trimmer capacitor C159 for zero beat (or lowest tone) in speaker.
- 5.4 Thereafter connect multimeter, switched to operate as DC voltmeter, to capacitor C156 and adjust coil L114 for maximum reading (approx. 2–3 V).

6. Adjustment of Oscillator and Signal-frequency Circuits

- 6.1 Connect signal generator via dummy aerial to aerial socket of receiver (HI-IMP AERIAL).
- 6.2 Function switch at HI-IMP. BFO ON.
- 6.3 Adjust the oscillator-, RF-, and mixer circuits, in that order. Adjust the oscillator circuit to zero beat, and the RF and mixer circuits for maximum reading on the front-panel meter. Signal generator output should be low enough so that meter does not read above 3. Use RF GAIN if necessary.
- 6.4 Adjustment is performed at the following points:

| Band | Frequency | Adjustment Points | |
|------|-----------|-------------------|--------------|
| | | Zero Beat | Max. Reading |
| LW | 155 kHz | L112 | L104, L108 |
| | 250 kHz | C123 | C107, C115 |
| NW | 260 kHz | L111 | L103, L107 |
| | 410 kHz | C124 | C108, C116 |
| MW | 550 kHz | L110 | L102, L106 |
| | 1500 kHz | C122 | C106, C114 |
| SW | 1800 kHz | L109 | L101, L105 |
| | 4200 kHz | C121 | C105, C113 |

7. Adjustment of Tone Filter

Adjust parallel resonant circuit L301, C301 with dust core of L301 at 1 kHz.

Cut-off frequencies are:

HIGH: 4 kHz MED: 1.2 kHz LOW: 0.6 kHz.

8. Adjustment of FM Intermediate Frequency:

- 8.1 Connect signal generator through capacitor (approx. 10 nF) to tuner test point, TP. Use swept signal with centre frequency of 10.7 MHz.
- 8.2 Measure intermediate-frequency characteristic at the collector of transistor T401 by means of an oscilloscope connected through a 10:1 probe (max. capacitance 10 pF), sensitivity 5 mV/cm AC.
- 8.3 With signal generator adjust signal height to 4 cm peak-peak and convenient sweep width.
- 8.4 Adjust intermediate-frequency coil in tuner IFT for maximum response and symmetrical curve form.

9. Adjustment of Detector Circuit:


- 9.1 Set signal generator output to approx. 50 μ V.
- 9.2 Connect oscilloscope through above-mentioned probe to detector output (capacitor C407), sensitivity 20 mV/cm AC.
- 9.3 Adjust coil L401 for symmetrical S-curve form.


10. Adjustment of Indicator Circuit:

- 10.1 Remove connection from test point TP and set tuning control to a frequency where only hiss is present (no station).
- 10.2 Switch multimeter to operate as DC voltmeter and connect to detector output (capacitor C407).
- 10.3 A DC voltage reading should be obtained that equals the no-signal voltage (approx. 5–6 V).
- 10.4 Thereafter apply to test point TP an unmodulated 500 μ V signal. Set the frequency (about 10.7 MHz) so that the DC voltage reading equals the no-signal voltage.
- 10.5 Adjust coil L402 for maximum reading on receiver's meter.
- 10.6 Adjust maximum reading to approx. 4 by means of potentiometer P401.
- 10.7 Repeat item 10.5 if necessary.

11. Tuner

FM tuner alignment points are indicated on the tuner's screen and correspond with those on the diagram. Should a defect develop in the tuner it is recommended to replace it.





R108/R109

| Symbol | Description | Manufact. | |
|--------|---|-------------|-------------------|
| C101 | Not used | | |
| C102 | Not used | | |
| C103 | Capacitor polystyrene 180pF \pm 1% 500V | Philips | 2222 427 41801 |
| C104 | Capacitor polystyrene 180pF \pm 1% 500V | Philips | 2222 427 41801 |
| C105 | Capacitor trimmer 9 - 60 pF | Dau-Teflon | 109. 4901. 060 |
| C106 | Capacitor trimmer 9 - 60 pF | Dau-Teflon | 109. 4901. 060 |
| C107 | Capacitor trimmer 9 - 60 pF | Dau-Teflon | 109. 4901. 060 |
| C108 | Capacitor trimmer 9 - 60 pF | Dau-Teflon | 109. 4901. 060 |
| C109 | Not used | | |
| C110 | Not used | | |
| C111 | Capacitor polystyrene 150pF \pm 1% 500V | Philips | 2222 427 41501 |
| C112 | Capacitor polystyrene 150pF \pm 1% 500V | Philips | 2222 427 41501 |
| C113 | Capacitor trimmer 9 - 60 pF | Dau-Teflon | 109. 4901. 060 |
| C114 | Capacitor trimmer 9 - 60 pF | Dau-Teflon | 109. 4901. 060 |
| C115 | Capacitor trimmer 9 - 60 pF | Dau-Teflon | 109. 4901. 060 |
| C116 | Capacitor trimmer 9 - 60 pF | Dau-Teflon | 109. 4901. 060 |
| C117 | Capacitor ceramic NPO 27 pF \pm 10% 400V | Ferroperm | 9/0112,9 |
| C118 | Not used | | |
| C119 | Capacitor polystyrene 470pF \pm 1% 250V | Philips | 2222 426 44701 |
| C120 | Capacitor polystyrene 620pF \pm 1% 125V | Philips | 2222 425 46201 |
| C121 | Capacitor trimmer 6 - 38 pF | Dau-Teflon | 109. 3901. 038 |
| C122 | Capacitor trimmer 6 - 38 pF | Dau-Teflon | 109. 3901. 038 |
| C123 | Capacitor trimmer 6 - 38 pF | Dau-Teflon | 109. 3901. 038 |
| C124 | Capacitor trimmer 6 - 38 pF | Dau-Teflon | 109. 3901. 038 |
| C125 | Capacitor polystyrene 1800pF \pm 1% 125V | Philips | 2222 425 41802 |
| C126 | Capacitor polystyrene 510pF \pm 1% 250V | Philips | 2222 426 45101 |
| C127 | Capacitor polystyrene 820pF \pm 1% 125V | Philips | 2222 425 48201 |
| C128 | Capacitor polystyrene 620pF \pm 1% 125V | Philips | 2222 425 46201 |
| C129 | Capacitor variable 3 x 532 pF | Jackson | Type E 4507/3/532 |
| C130 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C131 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C132 | Capacitor tantal 10uF 16V | Ero | ETP-3 |
| C133 | Capacitor tantal 10uF 16V | Ero | ETP-3 |
| C134 | Capacitor tantal 10uF 16V | Ero | ETP-3 |
| C135 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C136 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C137 | Capacitor tantal 10uF 16V | Ero | ETP-3 |
| C138 | Capacitor polystyrene 4700pF \pm 1% 63V | Philips | 2222 424 44702 |
| C139 | Capacitor polystyrene 4700pF \pm 1% 63V | Philips | 2222 424 44702 |
| C140 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |

R108/R109

| Symbol | Description | Manufact. | |
|--------|---|-------------|----------------|
| C141 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C142 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C143 | Capacitor tantal 10 uF 16V | Ero | ETP - 3 |
| C144 | Capacitor tantal 10 uF 16V | Ero | ETP - 3 |
| C145 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C146 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C147 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C148 | Capacitor polystyrene 3,3nF \pm 1% 63V | Philips | 2222 424 43302 |
| C149 | Capacitor tantal 10 uF 16V | Ero | ETP - 3 |
| C150 | Capacitor polystyrene 1000pF \pm 1% 125V | Philips | 2222 425 41002 |
| C151 | Capacitor polystyrene 2200pF \pm 1% 63V | Philips | 2222 424 42202 |
| C152 | Capacitor polystyrene 100 pF \pm 1% 500V | Philips | 2222 427 41001 |
| C153 | Capacitor polystyrene 4,7 nF \pm 1% 63V | Philips | 2222 424 44702 |
| C154 | Capacitor tantal 10 uF 16V | Ero | ETP - 2 |
| C155 | Capacitor polystyrene 56 pF \pm 1% 500V | Philips | 2222 427 45609 |
| C156 | Capacitor polyester 22 nF \pm 10% 250V | Philips | 2222 342 45223 |
| C157 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C158 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C159 | Capacitor trimmer 9 - 60 pF | Dau-Teflon | 109. 4901. 060 |
| C160 | Capacitor tantal 10 uF 16V | Ero | ETP - 2 |
| C161 | Capacitor polystyrene 1000pF \pm 1% 125V | Philips | 2222 425 41002 |
| C162 | Capacitor polystyrene 1000pF \pm 1% 125V | Philips | 2222 425 41002 |
| C163 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C164 | Capacitor tantal 68uF \pm 10% 16V | Ero | ETQ - 5 |
| C165 | Capacitor polyester 22nF \pm 10% 250V | Philips | 2222 342 45223 |
| C166 | Capacitor tantal 10 uF 16V | Ero | ETP - 2 |
| C167 | Capacitor polyester 22nF \pm 10% 250V | Philips | 2222 342 45223 |
| C168 | Capacitor tantal 10 uF 16V | Ero | ETP - 2 |
| C169 | Capacitor polystyrene 1500pF \pm 1% 63V | Philips | 2222 424 41502 |
| C170 | Capacitor tantal 1 uF 35V | Ero | ETP - 1 |
| C171 | Capacitor polystyrene 2200pF \pm 1% 63V | Philips | 2222 424 42202 |
| C172 | Capacitor tantal 33 uF 10V | Ero | ETP - 3 |
| C173 | Capacitor tantal 33 uF 10V | Ero | ETP - 3 |
| C174 | Capacitor electrolytic 1000uF 16V | Siemens | B41010-A4108-T |
| C175 | Capacitor polystyrene 150pF \pm 1% 500V | Philips | 2222 427 41501 |
| C176 | Capacitor polyethylene 0,1uF \pm 20% 100V | Philips/Ero | 2222 344 24104 |
| C177 | Capacitor electrolytic 1000uF 16V | Siemens | B41010-A4108-T |
| C178 | Capacitor tantal 68uF \pm 10% 16V | Ero | ETQ - 5 |
| C179 | Capacitor electrolytic 1000uF 16V | Siemens | B41010-A4108-T |
| C180 | Capacitor electrolytic 1000uF 16V | Siemens | B41010-A4108-T |

R108/R109

| Symbol | Description | | | Manufact. | |
|--------|------------------------|------------------|------|------------|----------------|
| C181 | Capacitor electrolytic | 100uF | 25V | Siemens | B41283-B5107-T |
| C182 | Capacitor polyester | 0,1uF | 250V | Arco | Minidip B |
| C183 | Capacitor polyester | 0,1uF | 250V | Arco | Minidip B |
| C184 | Capacitor polyester | 0,1uF | 250V | Arco | Minidip B |
| C185 | Capacitor ceramic | 33 pF±10% | 400V | Ferroperm | 9/0116,3 |
| D101 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D102 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D103 | Diode germanium | | | Ph/Sie | AA119 |
| D104 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D105 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D106 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D107 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D108 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D109 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D110 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D111 | Not used | | | | |
| D112 | Diode zeener | 9,1V | 5W | Motorola | 1N5346 B |
| D113 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D114 | Diode silicium | | | Ph/Sie/Tex | 1N4148/1S921 |
| D115 | Diode silicium | | | Motorola | 1N4002 |
| F101 | Fuse 5 x 20mm | 1 AMP | Slow | Wickmann | 1AT |
| GL101 | Neon Bulb | | | H. Limited | Type 3L |
| IC101 | Integrated circuit | | | NS/RCA | LM3053/CA3053 |
| IC102 | Integrated circuit | | | Philips | TBA 570 Q |
| J101 | Aerial socket | | | Bell & Lee | L603/Black |
| J102 | DF socket | | | Hirschmann | Meb 60 |
| J103 | Phone jack | (without switch) | | Cliff | Type S1 |
| J104 | Power socket | | | Hirschmann | Mesei 60F |
| L101 | Aerial coil SW | TL 125 | | S.P. | 6-0-20466 |
| L102 | Aerial coil MW | TL 126 | | S.P. | 6-0-20467 |
| L103 | Aerial coil NW | TL 127 | | S.P. | 6-0-20468 |
| L104 | Aerial coil LW | TL 128 | | S.P. | 6-0-20469 |
| L105 | RF coil SW | TL 129 | | S.P. | 6-0-20470 |
| L106 | RF coil MW | TL 130 | | S.P. | 6-0-20471 |
| L107 | RF coil NW | TL 131 | | S.P. | 6-0-20472 |
| L108 | RF coil LW | TL 132 | | S.P. | 6-0-20473 |

R108/R109

| Symbol | Description | | Manufact. | |
|--------|----------------------|-------------------|-----------|----------------|
| L109 | Osc. coil SW | TL 133 | S.P. | 6-0-20474 |
| L110 | Osc. coil MW | TL 134 | S.P. | 6-0-20475 |
| L111 | Osc. coil NW | TL 135 | S.P. | 6-0-20476 |
| L112 | Osc. coil LW | TL 136 | S.P. | 6-0-20477 |
| L113 | IF trap coil | TL 137 | S.P. | 6-0-20478 |
| L114 | Beat osc. coil | TL 138 | S.P. | 6-0-20479 |
| L115 | IF coil | TL 139 | S.P. | 6-0-20480 |
| L116 | Filter coil | | S.P. | TL 079 |
| L117 | Filter coil | | S.P. | TL 079 |
| LA101 | Dial lamp 12V | | Philips | 80030 |
| LS101 | Speaker 8 ohm | | Videbæk | 21/8 TV-LG |
| M101 | Meter 100 uA | | Bertram | Type 689-100uA |
| P101 | Potentiometer log | 50 K ohm W/switch | Piher | 21E 6 s/i |
| P102 | Potentiometer | 10 K ohm lin | Piher | 21E 6 s/i |
| P103 | Potentiometer trimme | 100 ohm | Ph/Ruwido | 2322 410 03301 |
| P104 | Potentiometer trimme | 470 ohm | Ph/Ruwido | 2322 410 03303 |
| P105 | Potentiometer trimme | 10 K ohm | Ph/Ruwido | 2322 410 03307 |
| R101 | Resistor | 9,1K ohm 0,33W | Philips | 2322 101 33912 |
| R102 | Resistor | 15 K ohm 0,33W | Philips | 2322 101 33153 |
| R103 | Resistor | 470 ohm 0,33W | Philips | 2322 101 33471 |
| R104 | Resistor | 10 K ohm 0,33W | Philips | 2322 101 33103 |
| R105 | Resistor | 470 ohm 0,33W | Philips | 2322 101 33471 |
| R106 | Resistor | 470 ohm 0,33W | Philips | 2322 101 33471 |
| R107 | Resistor | 4,7K ohm 0,33W | Philips | 2322 101 33473 |
| R108 | Resistor | 39 ohm 0,33W | Philips | 2322 101 33399 |
| R109 | Resistor | 680 ohm 0,33W | Philips | 2322 101 33681 |
| R110 | Resistor | 100 ohm 0,33W | Philips | 2322 101 33101 |
| R111 | Resistor | 27 K ohm 0,33W | Philips | 2322 101 33273 |
| R112 | Resistor | 3,3K ohm 0,33W | Philips | 2322 101 33332 |
| R113 | Resistor | 18 K ohm 0,33W | Philips | 2322 101 33183 |
| R114 | Resistor | 15 K ohm 0,33W | Philips | 2322 101 33153 |
| R115 | Resistor | 680 ohm 0,33W | Philips | 2322 101 33681 |
| R116 | Resistor | 10 ohm 0,33W | Philips | 2322 101 33109 |
| R117 | Resistor | 2,2K ohm 0,33W | Philips | 2322 101 33222 |
| R118 | Resistor | 120 ohm 0,33W | Philips | 2322 101 33121 |
| R119 | Resistor | 680 ohm 0,33W | Philips | 2322 101 33681 |
| R120 | Resistor | 1,2K ohm 0,33W | Philips | 2322 101 33122 |

| R108/R109 | | | | | |
|-----------|-------------|------------------|-------|-----------|----------------|
| Symbol | Description | | | Manufact. | |
| R121 | Resistor | 5,6K ohm | 0,33W | Philips | 2322 101 33562 |
| R122 | Resistor | 680 ohm | 0,33W | Philips | 2322 101 33681 |
| R123 | Resistor | 5,6K ohm | 0,33W | Philips | 2322 101 33562 |
| R124 | Resistor | 560 ohm | 0,33W | Philips | 2322 101 33561 |
| R125 | Resistor | 4,7K ohm | 0,33W | Philips | 2322 101 33472 |
| R126 | Resistor | 2,7K ohm | 0,33W | Philips | 2322 101 33272 |
| R127 | Resistor | 100 ohm | 0,33W | Philips | 2322 101 33101 |
| R128 | Resistor | 22 K ohm | 0,33W | Philips | 2322 101 33223 |
| R129 | Resistor | 4,7K ohm | 0,33W | Philips | 2322 101 33472 |
| R130 | Resistor | 2,2K ohm | 0,33W | Philips | 2322 101 33222 |
| R131 | Resistor | 100K ohm | 0,33W | Philips | 2322 101 33104 |
| R132 | Resistor | 5,6K ohm | 0,33W | Philips | 2322 101 33562 |
| R133 | Resistor | 3,3K ohm | 0,33W | Philips | 2322 101 33332 |
| R134 | Resistor | 22 K ohm | 0,33W | Philips | 2322 101 33223 |
| R135 | Resistor | 15 K ohm | 0,33W | Philips | 2322 101 33153 |
| R136 | Resistor | 680 ohm | 0,33W | Philips | 2322 101 33681 |
| R137 | Resistor | 1,5K ohm | 0,33W | Philips | 2322 101 33152 |
| R138 | Resistor | 2,2K ohm | 0,33W | Philips | 2322 101 33222 |
| R139 | Resistor | 2,7K ohm | 0,33W | Philips | 2322 101 33272 |
| R140 | Resistor | 68 K ohm | 0,33W | Philips | 2322 101 33683 |
| R141 | Resistor | 100K ohm | 0,33W | Philips | 2322 101 33104 |
| R142 | Resistor | 390 ohm | 0,33W | Philips | 2322 101 33391 |
| R143 | Resistor | 10 ohm | 0,33W | Philips | 2322 101 33109 |
| R144 | Resistor | 33 K ohm | 0,33W | Philips | 2322 101 33333 |
| R145 | Resistor | 390 ohm | 0,33W | Philips | 2322 101 33391 |
| R146 | Resistor | 330 ohm | 0,33W | Philips | 2322 101 33331 |
| R147 | Resistor | 0,68 ohm±10% | 0,7W | Resista | RN 3 |
| R148 | Resistor | 5,6K ohm | 0,33W | Philips | 2322 101 33562 |
| R149 | Resistor | 3,3K ohm | 0,33W | Philips | 2322 101 33332 |
| R150 | Resistor | 330 ohm | 0,33W | Philips | 2322 101 33331 |
| R151 | Resistor | 15 ohm | 0,33W | Philips | 2322 101 33159 |
| R152 | Resistor | 4,7K ohm | 0,33W | Philips | 2322 101 33472 |
| R153 | Resistor | 820 ohm | 0,33W | Philips | 2322 101 33821 |
| R154 | Resistor | 270 ohm | 0,33W | Philips | 2322 101 33271 |
| R155 | Resistor | 100 ohm | 0,33W | Philips | 2322 101 33101 |
| R156 | Resistor | 100K ohm | 0,33W | Philips | 2322 101 33104 |
| R157 | Resistor | R108 ONLY 47 ohm | 0,33W | Philips | 2322 101 33479 |
| R158 | Resistor | 180 ohm | 4,2W | Philips | 2322 330 22181 |
| R159 | Resistor | 33 ohm | 0,33W | Philips | 2322 101 33339 |
| R160 | Resistor | 10 ohm | 0,33W | Philips | 2322 101 33109 |
| R161 | Resistor | 3,3K ohm | 0,33W | Philips | 2322 101 33332 |

R108/R109

| Symbol | Description | Manufact. | |
|--------|---|-----------|-----------------|
| R162 | Resistor 1,2K ohm 0,33W | Philips | 2322 101 33122 |
| X101 | Ceramic resonator $f_S = 452 \text{ kHz} \pm 1 \text{ kHz}$ | CRL | FP 2 S 26 |
| S101 | Band switch | Petrick | 70624/I |
| S102 | Function switch | MEC | 7-3-20352 |
| S103 | Battery and Test switch | Promimet | 4032 N |
| S104 | Power switch (part of P101) | | |
| S105 | Light switch R108 ONLY | MEC | 7-3-20566A |
| | Light switch R109 ONLY | C & K | INC 8532/A 7760 |
| S106 | Range switch R109 ONLY | MEC | 7-3-20758 |
| T101 | Transistor | Phil/Tex | BF 199, BF 597 |
| T102 | Transistor | Sie/Phil | BC 147A |
| T103 | Transistor | Sie/Phil | BC 147A |
| T104 | Transistor | Sie/Phil | BC 147A |
| T105 | Transistor | Sie/Telef | BC 140 |
| T106 | Transistor | Sie/Telef | BC 160 |
| T107 | Transistor | Motorola | 2N 3055 |
| TR101 | Output transformer | Tradania | TD 2344 |

R108/R109

| Symbol | Description | | | Manufact. | |
|--------|-----------------------|---------------------|-------|-----------|----------------|
| C201 | Capacitor polystyrene | 560pF \pm 1% | 125V | Philips | 2222 425 45601 |
| C202 | Capacitor polystyrene | 180pF \pm 1% | 500V | Philips | 2222 427 41801 |
| C203 | Capacitor polystyrene | 330pF \pm 1% | 250V | Philips | 2222 426 43301 |
| C204 | Capacitor polystyrene | 360pF \pm 1% | 250V | Philips | 2222 426 43601 |
| C205 | Capacitor polystyrene | 68pF \pm 1% | 500V | Philips | 2222 427 46809 |
| C206 | Capacitor polystyrene | 270pF \pm 1% | 500V | Philips | 2222 427 42701 |
| C207 | Capacitor polystyrene | 270pF \pm 1% | 500V | Philips | 2222 427 42701 |
| C208 | Capacitor polystyrene | 270pF \pm 1% | 500V | Philips | 2222 427 42701 |
| C209 | Capacitor polystyrene | 560pF \pm 1% | 125V | Philips | 2222 425 45601 |
| L201 | IF filter coil | TL 140 | | S.P. | 6-0-20481 |
| L202 | IF filter coil | TL 140 | | S.P. | 6-0-20481 |
| R201 | Resistor | 10 K ohm | 0,33W | Philips | 2322 101 33103 |
| R202 | Resistor | 27 K ohm | 0,33W | Philips | 2322 101 33273 |
| X201 | Ceramic resonator | 452 KHz \pm 1 KHz | | CRL | FP 2 S 26 |
| X202 | Ceramic resonator | 452 KHz \pm 1 KHz | | CRL | FP 2 S 26 |
| X203 | Ceramic resonator | 452 KHz \pm 1 KHz | | CRL | FP 2 S 26 |
| X204 | Ceramic resonator | 452 KHz \pm 1 KHz | | CRL | FP 2 S 26 |

| A | | R108/R109 | |
|--------|--|------------|----------------|
| Symbol | Description | Manufact. | |
| C301 | Capacitor polyethylene 0,15uF \pm 20% 100V | Phil/Ero | 2222 344 24154 |
| C302 | Capacitor polyester 10nF \pm 10% 250V | Philips | 2222 342 45103 |
| C303 | Capacitor polystyrene 2,2nF \pm 1% 63V | Philips | 2222 424 42202 |
| C304 | Capacitor tantal 1uF 35V | Ero | ETP - 1 |
| D301 | Diode silicium | Ph/Sie/Tex | 1N4148/1S921 |
| L301 | AF filter coil TL 141 | S.P. | 6-0-20482 |
| R301 | Not used | | |
| R302 | Resistor 47 K ohm 0,33W | Philips | 2322 101 33473 |
| R303 | Resistor 39 K ohm 0,33W | Philips | 2322 101 33393 |
| R304 | Resistor 2,7 K ohm 0,33W | Philips | 2322 101 33272 |
| S301 | Tone switch | MEC/Lorlin | 7-3-20351B |

| Symbol | Description | Manufact. | |
|--------|--|------------|------------------------------|
| C401 | Capacitor ceramic 1,8nF -20/+80% 400V | Ferroperm | 9/0141,9 |
| C402 | Capacitor ceramic 1,8nF -20/+80% 400V | Ferroperm | 9/0141,9 |
| C403 | Capacitor polyester 22 nF \pm 10% 250V | Philips | 2222 342 45223 |
| C404 | Capacitor polyester 10 nF \pm 10% 250V | Philips | 2222 342 45103 |
| C405 | Capacitor polyester 10 nF \pm 10% 250V | Philips | 2222 342 45103 |
| C406 | Capacitor polystyrene 470pF \pm 5% 25V | Suf./Mial | HS7/A Type 610,1 |
| C407 | Capacitor polyester 22 nF \pm 10% 250V | Philips | 2222 342 45223 |
| C408 | Capacitor ceramic 56 pF \pm 5% 400V | Ferroperm | 9/0122,9 |
| C409 | Capacitor polystyrene 100pF \pm 5% 25V | Sie./Mial | B31111-A3101-J Type 610,1 |
| C410 | Capacitor polyester 10 nF \pm 10% 250V | Philips | 2222 342 45103 |
| C411 | Capacitor polyester 10 nF \pm 10% 250V | Philips | 2222 342 45103 |
| C412 | Capacitor ceramic 10nF -20/+80% 30V | Ferroperm | 9/0145,9 |
| C413 | Capacitor polyester 10 nF \pm 10% 250V | Philips | 2222 342 45103 |
| C414 | Capacitor polyester 10 nF \pm 10% 250V | Philips | 2222 342 45103 |
| C415 | Capacitor ceramic 10nF -20/+80% 30V | Ferroperm | 9/0145,9 |
| C416 | Capacitor polyester 10 nF \pm 10% 250V | Philips | 2222 342 45103 |
| C417 | Capacitor polyester 10 nF \pm 10% 250V | Philips | 2222 342 45103 |
| C418 | Capacitor ceramic 10 pF \pm 5% 400V | Ferroperm | 9/0112,9 |
| CH401 | Drossel coil 10 uH KGRD 5x10/R10 | K.K. & B. | Dualoric |
| CH402 | Drossel -3pc. ferroxcube beads | Philips | 4322 020 34400 |
| D401 | Diode zeener 5,1V 1W | Motorola | 1N4733A |
| D402 | Diode germanium | Ph./Sie. | AA119 |
| D403 | Diode silicium | Ph/Sie/Tex | 1N4148/1S921 |
| IC401 | Integrated circuit | Siemens | TBA 120S |
| L401 | Detector coil TL149 | S.P. | 6-0-20784 |
| L402 | Indicator coil TL150 | S.P. | 6-0-20785 |
| P401 | Potentiometer trimme 220 ohm | Ph/Ruwido | 2322 410 03302 0052-600 |

A

R109

| Symbol | Description | | | Manufact. | |
|--------|----------------|--------------|-------|-----------|----------------|
| R401 | Resistor | 470 ohm | 0,33W | Philips | 2322 101 33471 |
| R402 | Resistor | 1 K ohm | 0,33W | Philips | 2322 101 33102 |
| R403 | Resistor | 560 ohm | 0,33W | Philips | 2322 101 33561 |
| R404 | Resistor | 6,8K ohm | 0,33W | Philips | 2322 101 33682 |
| R405 | Resistor | 2,2K ohm | 0,33W | Philips | 2322 101 33222 |
| R406 | Resistor | 100 ohm | 0,33W | Philips | 2322 101 33101 |
| R407 | Resistor | 470 ohm | 0,33W | Philips | 2322 101 33471 |
| R408 | Resistor | 47 ohm | 0,33W | Philips | 2322 101 33479 |
| R409 | Resistor | 470 ohm | 0,33W | Philips | 2322 101 33471 |
| R410 | Resistor | 220 ohm | 0,33W | Philips | 2322 101 33221 |
| R411 | Resistor | 1 K ohm | 0,33W | Philips | 2322 101 33102 |
| R412 | Resistor | 3,9K ohm | 0,33W | Philips | 2322 101 33392 |
| R413 | Resistor | 33 ohm | 0,33W | Philips | 2322 101 33339 |
| R414 | Resistor | 680 ohm | 0,33W | Philips | 2322 101 33681 |
| R415 | Resistor | 100 ohm | 0,33W | Philips | 2322 101 33101 |
| T401 | Transistor | | | Tex/Phil | BF597/BF199 |
| T402 | Transistor | | | Sie/Phil | BC 157A |
| X401 | Ceramic filter | 10,7 MHz | | TAIYO | CFM-107K-14 |
| TU401 | FM Tuner | 88 - 108 MHz | | MITSUMI | FC-A35 |

